



Disassembling Planet Eclipse Geo3 Grip

Remove the grip from the frame.

Written By: Rett Triplett



INTRODUCTION

In this guide, the grip will be removed so the battery, wires, or board can be accessed.



TOOLS:

- [5/64" Allen Wrench](#) (1)
-

Step 1 — Grip



- Remove the four screws from the grip with the 5/64" allen wrench. There are two on each side.

Step 2



- Pull the grip away from the frame.

Step 3



- Pull the grip through the opening.
- The grip is connected in the middle and is one piece.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 09:01:12 PM.